



# Bestcare Sling User Guide

## STAND ASSIST SLINGS




### WARNING!

Step 1: Check sling weight capacity for the patient being lifted. Do not exceed maximum safe working load.



Step 2: Review following procedures carefully, prior to attempting lift. Call with any questions.

Step 3: Position sling behind seated patient, with the 2 red pads under arms (Diagram 2).



Step 4: Cross padded belt over chest/stomach area and secure with snap buckle belt (Diagram 2).

Step 5: Loop straps A & B through black strap C and hook to corresponding a & b hooks on mast (Diagram 1 and 4).



Step 6: Have patient grasp handle bars and place feet on lift platform, with knees against black knee pad (Diagram 5).

Step 7: Keep arms outside all loops, and lean head slightly back (Diagram 5).

Step 8: Do not lock caster brakes to allow lift to properly balance weight.


Step 9: Begin the lift and transfer as in Diagram 6.

\* Optional buttock strap shown in Diagram 6 offers extra support and attaches to extra loops on spreader bar below a and b.



#### SLING LOOP OPTIONS

- Long Loop- reclined position.
- Center Loop- semi-reclined position
- Short Loop- most upright position



1-877-822-9033