

# Bestcare Sling User Guide

## UNIVERSAL SLINGS

Diagram 2





Diagram 1



### WARNING!

Step 1: Check sling weight capacity for the patient being lifted. Do not exceed maximum safe working load.

Step 2: Review following procedures carefully prior to attempting lift. Call with any questions.

Step 3: Position the sling under and behind the back with color adjustment strap on outside. A & B should be at shoulder height.

Step 4: Pull the leg straps E & F down behind patient, and between legs as in Diagram 3.

Step 5: Loop E & F through each other as in Diagram 4.

Step 6: Attach all loops A - F to all corresponding hooks a - f on spreader bar (Diagram 1).

Step 7: Do not lock caster brakes to allow lift to properly balance weight.

Step 8: Begin the lift process and transfer as in Diagram 5.

Diagram 3





Diagram 4



### SLING LOOP OPTIONS

Long Loop- reclined position.


Center Loop- semi-reclined position

Short Loop- most upright position

Long loop

Center loop

Short loop



1-877-822-9033