

BestSling User Guide

UNIVERSAL SLINGS

Diagram 2




Diagram 1





Diagram 3



Diagram 4





WARNING!

- Step 1: Check sling weight capacity for the patient being lifted. Do not exceed maximum safe working load.
- Step 2: Review following procedures carefully prior to attempting lift. Call with any questions.
- Step 3: Position the sling under and behind the user with color adjustment straps on the outside. A & B should be at shoulder height.
- Step 4: Pull the leg straps E & F down behind patient, and between legs as in Diagram 3.
- Step 5: Loop E & F through each other as in Diagram 4.
- Step 6: Attach all loops A - F to all corresponding hooks A - F on spreader bar (Diagram 1).
- Step 7: Do not lock caster brakes to allow lift to properly balance weight.
- Step 8: Begin the lift process and transfer as in Diagram 5.

SLING LOOP OPTIONS

- Long Loop- reclined position.
- Center Loop- semi-reclined position
- Short Loop- most upright position



1-877-822-9033